

Attention: Store Manager / Electronics Department Manager

Re: Emerson Research SmartSet® Clock Radio Display

Enclosed is your Interactive Display for use with **Emerson Research SmartSet®** clock radios. The AC power supply to the clock radio is momentarily interrupted whenever the red “**DEMO**” button is pressed. The clock display will go blank for 1 - 2 seconds and then the clock will automatically re-set itself to the correct Year, Month, Date, Day, and Time.

Place the **Emerson Research SmartSet®** clock radio on the Display platform and connect the clock radio power cord to the outlet on the back of the Display. Then connect the power cord from the Display to any convenient 120V 60Hz AC outlet.

IMPORTANT:

- If the clock radio has a Dimmer control, make sure the Dimmer is set to the normal (**HIGH**) position.
- All SmartSet® clock radios use Eastern Time as the default Time Zone setting. The first time the clock radio is connected to AC, it will set itself to the correct Eastern Time. If you are not in the Eastern Time zone, be sure to set the clock to your own time zone before placing it on the Display. Refer to the clock radio Owner’s Manual for details.
- This Display was designed to use with **Emerson Research SmartSet®** clock radios only. **DO NOT USE WITH ANY OTHER BRAND OF CLOCK RADIOS OR WITH ANY OTHER PRODUCTS.**
- If you have any difficulties with the set up or operation of this Display, contact the Emerson Customer Service Hotline at: **1-800-898-9020**.